


MCAS Miramar Air Show

Fly-in/Fly-off Procedures

You are in Bravo airspace

Tower - 298.925, 135.2

Ground - 307.325, 128.625



For IFR approach plates see following pages.

For additional information visit www.SkyVector.com, select airport and type NKX for MCAS Miramar.

Arrival Procedures (Civil)▶

- From MYF, report Torrey Pines GC. 1500 MSL. Pass north of merge. (Not Direct).
- From SEE, report Black MTN. 1500 MSL. (Not Direct).
- From shore, report Del Mar Race Track 1500 MSL.
- From inland, Report Black MTN. 1500 MSL.
- All aircraft then report Miramar Reservoir for landing clearance.
- Performer aircraft exit right, park west of Tower.
- Static Display aircraft turn right on parallel eastbound to approach end for parking.

Departure Procedures (Civil) ---▶

- Northwest via I-5/I-805 merge.
- North via Black MTN.
- East via left downwind departure towards SEE.

Military/Tactical Arrival & Departure Procedures

- Overhead break @ 2100 MSL left traffic. Downwind 1600 MSL. Remain north of Highway 52. No short field arresting gear (E-28).
- Departure via IFR Departure Procedure. Commence right turn prior to end of runway for noise abatement.